


NGC-UIT2-ORD or NGC-UIT2-EX to UIT3-EX

Conversion instructions





CERTIFICATIONS / APPROVALS

- TYPE 4X, IP65 protection on front panel
- FCC Part15 Subpart B/ICES 003 Class A
- CE marking
 - Low Voltage Directive (2014/35/EU) EN 62368-1:2014 / A11:2017
 - EMC Directive (2014/30/EU) EN 55032:2015 EN 55035:2017
- Conforms to UL 62368-1, 2nd Ed, 2014-12-01; CAN/CSA C22.2 No. 62368-1-14, 2nd Ed, Issued: 2014-12-01; UL 60950-1, 2nd Edition, 2019-05-09; CAN/CSA C22.2 No. 60950-1-07, 2nd Edition, 2014-10
- ATEX Directive (2014/34/EU)
 - EN 60079-0:2017
 - EN 60079-11:2012
 - EN 60079-7: 2015 +A1:2018
- IECEx
 - IEC 60079-0 2017
 - IEC 60079-11 2012
 - IEC 60079-7, 5.1 Ed



II 3 G Ex ic ec IIC T5 Gc

Refer to the nVent RAYCHEM NGC-UIT3-EX installation manual for full specifications.

DESCRIPTION

These instructions will guide the experienced installer in converting an existing nVent RAYCHEM NGC-UIT2-ORD or UIT2-EX installation to an nVent RAYCHEM NGC-UIT3-EX installation.

TOOLS REQUIRED

- 5/16 in (8 mm) nut driver
- 3/8 in (10 mm) nut driver

KIT CONTENTS

Qty	Description	Manufacturer	Manufacturer Part Number
3	Alarm Relay Sockets	Square D	NR45B
3	12 V SPDT Alarm Relays	Square D	8501RSD34V51
1	NGC-UIT3-EX	nVent	10332-034
4	Terminal Block	Phoenix Contact	3031364
2	Grounding Terminal Block	Phoenix Contact	3031380
2	End Cover	Phoenix Contact	3030420
1	20' Shielded Twisted Pair RS-485 wire		T0000929


⚠ WARNING:

Do not connect/disconnect equipment unless power has been switched off or the area is known to be non-hazardous.
Ne débranchez pas l'équipement tant que l'alimentation est coupée ou que la zone est connue pour être non dangereuse.


⚠ IMPORTANT:

- Use appropriately classified and listed Power Supply (Limited Power Source, or LPS). Follow all applicable wiring codes and regulations.
- Peripheral equipment must be suitable for the location in which it is used.
- There are no non-incendive circuits or non-incendive field wiring within or associated with the unit.
- Only technically qualified service personnel are permitted to install or service the equipment.
- Do not disassemble the system – no user-serviceable parts inside.
- Do not operate the equipment if it has been damaged.
- Utilisez une source d'alimentation correctement classée et répertoriée (source d'énergie limitée ou LPS). Suivez tous les codes et normes de câblage applicables.
- L'équipement périphérique doit être adapté à l'emplacement dans lequel il est utilisé.
- Il n'y a pas de circuits non incendiaires ni de câbles de terrain non incendiaires à l'intérieur ou associés avec l'équipement.
- Seul le personnel qualifié est autorisé à installer ou à entretenir l'équipement.
- Ne pas démonter le système – aucune pièce interne ne peut être réparée par l'utilisateur.
- N'utilisez pas l'équipement s'il a été endommagé.


NGC-UIT3-EX CONNECTION DIAGRAM




Top view




Side View



Front view




Bottom View




Back view

REMOVING THE NGC-UIT2-ORD OR UIT2-EX AND RELATED COMPONENTS


1. Prior to removing the existing UIT2-ORD or UIT2-EX from the panel door, disconnect the AC power and remove the power cord. Disconnect the two RS-485 cables from the unit as shown in the illustration below.
2. Remove the (12) 10-32 mounting nuts that secure the NGC-UIT2-ORD or UIT2-EX to the panel door. **Save the mounting hardware - it will be needed later to secure the UIT3-EX to the panel.**
3. Disconnect the RS-485 communications wiring from the two RS-232 to RS-485 converters, from the Adam Relay Output module and the DIN rail terminals. Carefully tag the RS-485 wiring coming from the CRM(s) and Remote connections, as these will need to be re-connected once the new components and NGC-UIT3-EX have been installed.




4. Next, disconnect the 12 Vdc wiring from the Adam module.




5. Disconnect any alarm relay wiring from the Adam module. Be sure to carefully label each set of wires (relay number, as well as NO, NC, and Common signals), as these will be reconnected to the new NGC-UIT3-EX once installed.




6. Remove components mounted to the DIN rail (Adam module, RS-232 to RS-485 converters).
7. Note that the four wiring terminals formerly used to connect the RS-485 signals should be retained since they will be re-used to distribute the 12 Vdc power to various components so they do not need to be removed. Further details are provided later in this document.




8. Install the new components onto the DIN rail as shown below. Note that the specific location or orientation of the components is not critical – choose the placement that makes wiring connections easiest to complete.



INSTALLING THE NGC-UIT3-EX INTO THE PANEL




- Install the NGC-UIT3-EX into the cutout in the panel, and secure using the twelve 10-32 nuts/lockwashers retained when the original NGC-UIT2-ORD or UIT2-EX was removed in Step 2 above. Tighten the nuts to 0.9 N-m (8 in-lbs) of torque using the 3/8 in nut driver in the sequence shown in the diagram below to ensure proper sealing.




RECONNECT 12 VDC POWER TO COMPONENTS

10. Connect the 12 Vdc from the power supply used to power the CRM(s) boards to the DIN rail terminals as shown below. Be sure to connect the +12 V to the first terminal and the negative (common) to the third terminal. The jumpers installed in between terminals 1 & 2 as well as 3 & 4 should remain in place.
11. Connect the 12 Vdc from terminal 1 to each of the alarm relays as shown in the diagram below.
12. Connect 12 Vdc to the male power connector located on the left side of the NGC-UIT3-EX. The "+" lead should go from DIN terminal 2 to UIT3-EX terminal marked "9-30 Vdc" and the "-" lead should go from DIN terminal 4 to the UIT3-EX terminal marked "GND". Ensure that the cables are routed through the cable clamp as shown.




RECONNECT THE ALARM RELAY WIRING

- Connect 12 Vdc power from the "VIN" terminal on the NGC-UIT3-EX Relay Driver Output connector to DIN terminal 2 and connect from the "GND" terminal to DIN terminal 3 as shown in the diagram below.
- Connect the relay output terminals 1, 2, and 3 of the NGC-UIT2-EX Relay Driver Output connector to the Alarm Relays on the DIN rail as shown.




- Connect the Alarm Relay contacts to the appropriate alarm wiring that was disconnected in Step 5. Ensure that the NO, Common, and NC signals are assigned to the correct relays.




RECONNECT THE COMMUNICATIONS WIRING

16. Connect the RS-485 Field and Remote communications ports using shielded twisted pair wire included with the kit. Be sure to connect the Field Port terminals to the RS-485-1 serial port on the NGC-UIT3-EX, and the Remote port terminals to the RS-485-2 serial port on the NGC-UIT3-EX as shown below.
17. Reconnect the RS-485 field wiring (to/from the CRM(s) boards, RMMs, and other devices) that was disconnected in Step 3. Be careful to observe the polarity of the connections as well as ensuring that the shield connections are terminated as shown.
18. Repeat Step 20 for the Remote port (Host computer) connections.



RS-485 CONFIGURATION SWITCHES


The configuration switches are found on the bottom of the NGC-UIT3-EX. Refer to the table below for settings.



Switch	Position		Comments
	On	Off	
Pull-down	(As-shipped default) RS-485 network "-" signal is forced to a determinate state when idle.	RS-485 network "-" signal is not forced to a determinate state when idle.	One device (typically this NGC-UIT3-EX) on the RS-485 network should force the network "-" signal to a determinate state.
Pull-up	(As-shipped default) RS-485 network "+" signal is forced to a determinate state when idle.	RS-485 network "+" signal is not forced to a determinate state when idle.	One device (typically this NGC-UIT3-EX) on the RS-485 network should force the network "+" signal to a determinate state.
Termination	(As-shipped default) RS-485 network is terminated with 120-ohm resistor.	RS-485 network is not terminated.	Terminate the device (NGC-UIT3-EX or other) that is at each end of the RS-485 network, for a total of two terminated devices. No other devices on the network should be terminated.

RESET SWITCH

The Reset switch can be found on the bottom of the NGC-UIT3-EX. A pointed object is required to press the reset switch and restart the NGC-UIT software.



North America

Tel +1.800.545.6258
Fax +1.800.527.5703
thermal.info@nVent.com

Europe, Middle East, Africa

Tel +32.16.213.511
Fax +32.16.213.604
thermal.info@nVent.com

Asia Pacific

Tel +86.21.2412.1688
Fax +86.21.5426.3167
cn.thermal.info@nVent.com

Latin America

Tel +1.713.868.4800
Fax +1.713.868.2333
thermal.info@nVent.com



[nVent.com/RAYCHEM](https://www.nVent.com/RAYCHEM)