

Print Pocket

1. Verify you have all the parts needed to install the print pocket.
 - Print pocket (with tape adhered to back)
2. Determine desired print pocket location, and examine the surface for contaminants such as dust or oil. Dust should be removed by wiping surface with water dampened rag. For oil or grease, the surface should be wiped using a rag dampened with mineral spirits or isopropyl alcohol. After removing contaminants, thoroughly dry the surface using a clean, dry rag to remove moisture or flashing solvents.

CAUTION

When using flammable solvent, care should be used in the proper disposal and handling of these materials.

3. Remove protective backing from double-faced tape. Position the print pocket in the desired location, pressing the bottom edge firmly to assure good adhesion of double-faced adhesive to both substrates. With light pressure, slide finger along both side flanges to form a consistent film thickness along these flanges. Sealant will skin over in approximately fifteen minutes, with full cure occurring in twenty-four hours. Refrain from placing heavy objects or large quantities of documents inside print pocket for at least twenty-four hours.