



1. Remove four square knockouts in the back of the enclosure.
2. Insert carriage bolts through the back of enclosure, and fasten with the large standoff nuts.
3. Install panel over standoff nuts, secure in place with the washers and nuts as shown.