

## DMFK1, DMFK2 Mounting Foot Kit

CATALOG NUMBER	ENCLOSURE SIZE	L	M	N
	A x B			
D-MFK1	6.00 x 6.00	1.50	3.00	1.50
	8.00 x 6.00			
	8.00 x 8.00 10.00 x 8.00	2.50	3.00	2.50
D-MFK2	10.00 x 10.00	1.50	7.00	1.50
	12.00 x 10.00			
	12.00 x 12.00	2.50	7.00	2.50
	14.00 x 12.00 16.00 x 12.00			

1. Locate holes for mounting foot studs using the dimensions given.
2. Use center punch to mark hole centers. Drill four .219 inch diameter holes.
3. Deburr Holes
4. Insert mounting foot studs into drilled holes, and turn enclosure upright.
5. Lightly lubricate the sealing washer and press onto mounting foot stud, neoprene side down.
6. Thread nut onto stud and tighten to 15 to 20 in-lbs.
7. Repeat steps 4–6 to other end to complete installation.

