## Slides



## **PARTS LIST**

Side support with slide, Qty. (2) Side support extension, Qty. (2) Clip nut 10–32, Qty. (12) Lockwasher No. 10, Qty (12) Pan head screw 10–32x1/2, Qty (12) Pan head screw 8–32x1/4, Qty (8) Lockwasher No. 8, Qty. (8)

## INSTALLATION INSTRUCTIONS

- Mounting holes for slides can be spaced at one inch increments from 14 inch to 27 inch. On 14 inch and 16 inch spacing, the side support extensions are not required.
- 2. Position rack mounting angles inside enclosure to desired spacing.
- 3. Assemble the side support extensions to the side supports (if required) by sliding two clip nuts into place over the side supports. Fasten into place with two 10–32 screws to obtain proper spacing for mounting.
- 4. Slide two clip nuts onto each rack mounting angle (when used).
- Position each side support assembly between the two rack mounting angles and fasten with 10–32 screws and lockwashers.
- 6. No. 8–3Žx1/4 pan head screws and lockwashers are furnished to install users equipment to slides side support.

