


Stainless Steel Exhaust Grille Upgrade



INTRODUCTION

1. Before installing the stainless steel exhaust grille, read these instructions carefully. Failure to follow these instructions could cause unnecessary damage to the enclosure and/or other components.

MAINTAINANCE

1. Always disconnect power supply before inspecting or working on the cooling fan package or exhaust grille.

⚠ WARNING

To avoid electric shock and equipment damage, disconnect any power supplies to the enclosure before installing the stainless steel exhaust grille.

To avoid electric shock, do not energize any circuits before all internal and external electrical and mechanical clearances are checked to assure that all assembled equipment functions safely and properly.

