



## Fast-Operating Junction Box Clamp



### INSTALLATION INSTRUCTIONS:

1. Remove the clamp and clamp screws.
2. Insert clamp screw through the latch and shim with washers to get good gasket compression. If the latch is too loose, remove washers to tighten the latch. If the latch is too tight, add washers to loosen.

### OPERATION INSTRUCTIONS:

1. Lower lever to the hanging position.
2. Hook catch over cover hem.
3. Lift lever to vertical position to catch.

