

Instruction sheet for BD-80-100A & TD-80-100A series (€ (563900 / 563910 / 563920 / 563930 / 563940)

BD Two Pole Distribution Block, 80/100A BD-80-100A (563900)




BD Two Pole Distribution Block, 80/100AL BD-80-100AL (563910)




TD Four Pole Distribution Block, 80/100A TD-80-100A (563920)



TD Four Pole Distribution Block, 80/100AL TD-80-100AL (563930)



TD Four Pole Distribution Block, 80/100ALL TD-80-100ALL (563940)



Metric rigid stranded cable
Metric flexible stranded cable

			563900	563910	563920	563930	563940	Hole Ø		ŭ
⇒	10 - 25mm²	10 - 25mm²	x1	x2	x1	x2	x2	8,5mm		2 - 3 N.m
⇔	1,5 - 4mm²	0,75 - 4mm²	х3	х6	х3	x4	х6	4,5mm	\square \triangle	1,2 - 1,5 N.m
\(\rightarrow	2,5 - 6mm²	1,5 - 6mm²	х3	x7	х3	x5	х7	5,5mm		2 - 3 N.m

Note:

1. Tighten screws of unused galleries to torque of 0,5 - 1 N.m

- RNING:

 Nent products shall be installed and used only as indicated in nVent product instruction sheets and training materials. Instruction sheets are available at www.nVent.com and from your nVent customer service representative.

 NVent products must never be used for a purpose other than the purpose for which they were designed or in a manner that exceeds specified load ratings. All instructions must be <a href="https://creativecommons.org/rep-th/9/lowen/weight-be-th/9/l damage, serious bodily injury and/or death, and void your warranty.

All governing codes and regulations and those required by the job site must be observed.

Always use appropriate safety equipment such as eye protection, hard hat, and gloves as appropriate to the application.

nVent, CADDY, ERICO CADWELD, ERICO CRITEC, ERICO, ERIFLEX, and LENTON are owned by nVent or its global affiliates. All other trademarks are the property of their respective owners. nVent reserves the right to change specifications without prior notice.



