

108 SERIES TWO HOLE STRAP HANGER

USED FOR PVC PIPE ONLY.






PART NO.	PIPE DIA.
1080075EG	3/4"
1080100EG	1 "
1080125EG	1 1/4"
1080150EG	1 1/2"
1080200EG	2"

SCREWS PROVIDED

- 1. SNAP PVC PIPE INTO HANGER. DIMPLES HOLD PIPE IN PLACE.
- 2. MOUNT HANGER TO UNDER SIDE OF BEAM WITH SCREWS PROVIDED.
- 3. MAY ALSO BE USED ON TOP SIDE OF BEAM. (SEE BELOW)
- 4. INTENDED FOR USE AS A GUIDE WHEN THE PIPE IS INSTALLED ON THE TOP SIDE OF A BEAM. THIS IS DUE TO THE FACT THAT THE BEAM IS SUPPORTING THE WEIGHT OF THE PIPE. NOT THE HANGER.



- Pentair products shall be installed and used only as indicated in Pentair product instruction sheets and training materials. Instruction sheets are available at

- Pentair products shall be installed and used only as indicated in Pentair product instruction sheets and training materials. Instruction sheets are available at www.erico.pentair.com and from your Pentair customer service representative.

 PENTAIR products must never be used for a purpose other than the purpose for which they were designed or in a manner that exceeds specified load ratings. All instructions must be <a href="https://www.erico.pentair.com/pentair.c other purpose.

NOTE: All load ratings are for static conditions and do not account for dynamic loading such as wind, water or seismic loads, unless otherwise noted.

The customer is responsible for:
a. Conformance to all governing codes.
b. The integrity of structures to which the products are attached, including their capability of safely accepting the loads imposed, as evaluated by a qualified

c. Using appropriate industry standard hardware as noted above.

All governing codes and regulations and those required by the job site must be observed.

Always use appropriate safety equipment such as eye protection, hard hat, and gloves as appropriate to the application.

